

## Roll Curtain



1>>

Assemble the roll curtain crank handle and insert the crank into the curtain's bottom tube.



2>>

Turn the crank handle to roll the rear curtain up.



3>>

Once the curtain reaches the top continue rolling until curtain rests on top of the rear of the tarp system.



4>>


The roll curtain provides full height clearance at the rear of the system.

## Draw Curtain



1>>

Remove rope from hooks on the inside of the rear bow.



2>>

Pull rope to raise the curtain.



3>>

Once the curtain reaches the top, wrap the rope around the hooks on the inside of the rear bow.



4>>

The draw curtain is fast and easy to open and does not require a crank; the draw curtain does store below the rear bow when open.

## Rear Locks

### Attached Rear Handle



1>> Remove pin to allow access to handle.



2>> Remove handle and lock in cranking position.



3>> Crank rear lock until tarp system is loose.



4>> Lift the lock assembly and it automatically attaches to the rear bow.



5>> Slide the tarp system towards the front; the lock assembly travels with the rear bow, allowing full loading and loading access (no cumbersome ratchet posts or frame assemblies to remove).

### Removable Rear Handle




1>> Insert handle into rear lock.

## Front Locks



1>> To release the front bow from the bulkhead, crank attached handle until front bow is loose from hook on bulkhead (repeat on opposite side).



2>> Slide the tarp system towards the rear to allow access to front of trailer.